

# THERMOGUARD 400 (AS 109)

- |                           |                               |                                     |                                     |
|---------------------------|-------------------------------|-------------------------------------|-------------------------------------|
| 1) AS 34578-0700 KIT      | 9) AS 34569-0700 LG. WSHR     | 17) AS 34555-0700 H-SEAT TOOL       | <del>25) AS 34553-0700 SCREW</del>  |
| 2) AS 34564-0700 O'RING   | 10) AS 34570-0700 PACKING     | 18) AS 34545-0700 SHIELD            | <del>26) AS 23481-0921 BUTTON</del> |
| 3) AS 34601-0700 KIT      | 11) AS 34571-0700 PKG. NUT    | 19) AS 34546-0700 SCREW             | 27) AS 70613-0200 HANDLE            |
| 4) AS 34534-0700 SCREW    | 12) AS AS109 KIT              | 20) AS 34547-0700 ESCH              | 28) AS 34581-0700 WSHR KIT          |
| 5) AS 34565-0700 O'RING   | 13) AS 34572-0200 DOME COVER  | <del>21) AS 34548-0700 O'RING</del> | 29) AS 34582-0700 SPINDLE           |
| 7) AS 34567-0700 SM. WSHR | 14) AS 34573-0700 LOCKNUT     | <del>22) AS 38362-0900 PLATE</del>  | 30) AS 34567-0700 SHIELD            |
| 3) AS 34568-0700 O'RING   | 15) AS 34556-0700 C-SEAT TOOL | <del>23) AS 34550-0200 SCREW</del>  |                                     |
|                           | 16) AS 34576-0700 LIMIT STOP  | <del>24) AS 34552-0700 WASHER</del> |                                     |

