

THERMOGUARD 400 (AS 109)

- | | | | |
|---------------------------|-------------------------------|-------------------------------------|-------------------------------------|
| 1) AS 34578-0700 KIT | 9) AS 34569-0700 LG. WSHR | 17) AS 34555-0700 H-SEAT TOOL | 25) AS 34553-0700 SCREW |
| 2) AS 34564-0700 O'RING | 10) AS 34570-0700 PACKING | 18) AS 34545-0700 SHIELD | 26) AS 23481-0921 BUTTON |
| 3) AS 34601-0700 KIT | 11) AS 34571-0700 PKG. NUT | 19) AS 34546-0700 SCREW | 27) AS 70613-0200 HANDLE |
| 4) AS 34534-0700 SCREW | 12) AS AS109 KIT | 20) AS 34547-0700 ESCH | 28) AS 34581-0700 WSHR KIT |
| 5) AS 34565-0700 O'RING | 13) AS 34572-0200 DOME COVER | 21) AS 34548-0700 O'RING | 29) AS 34582-0700 SPINDLE |
| 7) AS 34567-0700 SM. WSHR | 14) AS 34573-0700 LOCKNUT | 22) AS 38362-0900 PLATE | 30) AS 34567-0700 SHIELD |
| 3) AS 34568-0700 O'RING | 15) AS 34556-0700 C-SEAT TOOL | 23) AS 34550-0200 SCREW | |
| | 16) AS 34576-0700 LIMIT STOP | 24) AS 34552-0700 WASHER | |

