


BRIGGS PRESSURE BALANCE VALVE



- Model Numbers:**
 1820B
 1830B
 1821B
 1831B
 1822B
 1832B
 1823B
 1833B
 1810B
 1811B
 1812B
 1813B
 1800B
 1801B
 1802B
 1803B

Parts List

* Part Number	Description	* Part Number	Description
1	Indicator Label	22	Throttle Discs (4)
2	Plug Button	23	Balance Chamber
3	Selector Screw(2)	24	Body
4	Washer	25	1/2" Pipe Plug
5	Dial Handle	26	Bonnet Nut
6	Spring	27	Bonnet Seal
7	Stem Guide	28	Bonnet
8	Dial Screw(2)	29	Bonnet Gasket
9	Escutcheon	30	Stem
10	Gasket	31	Plunger Spring
11	Rough-in Guide	32	Plunger
12	Screw	33	Plunger Disc
13	Limit Stop	34	Checkstop
14	Sleeve		
15	Bonnet Retainer	35	Bonnet Nut
16	Bonnet	36	Rubber Washer
17	"O" Ring	37	Metal Washer
18	"O" Ring	38	Stem
19	Washer	39	Rubber Disc
20	Spring	40	Checkstop Body
21	Stem Assembly		

Repair Kits List

Repair Kits Number	Items Included
800-030	17, 18, 20, 22 (4), 28 (2), 30 (2), 34 (2)
800-031	17, 18, 22 (4), 23
800-032	12, 13, 17, 18, 19, 20, 21, 22 (2)

Repair parts sold only in kit form per above.

* Not listed in parts price list as a standard replacement part.

PLUMBING PARTS DEPOT
 1160 Bradfield Rd.
 Roslyn, PA 19001
 Phone: 800-448-8977
 Fax: 215-886-4760