


**BRIGGS  
PRESSURE BALANCE  
VALVE**



- Model Numbers:**  
1820B  
1830B  
1821B  
1831B  
1822B  
1832B  
1823B  
1833B  
1810B  
1811B  
1812B  
1813B  
1800B  
1801B  
1802B  
1803B

**Parts List**

* Part Number	Description	* Part Number	Description
1	Indicator Label	22	Throttle Discs (4)
2	Plug Button	23	Balance Chamber
3	Selector Screw (2)	24	Body
4	Washer	25	1/2" Pipe Plug
5	Dial Handle	26	Bonnet Nut
6	Spring	27	Bonnet Seal
7	Stem Guide	28	Bonnet Gasket
8	Dial Screw (2)	29	Bonnet Gasket
9	Valve Body	30	Stem
10	Gasket	31	Plunger
11	Rough-in Guide	32	Spring
12	Screw	33	Plunger Disc
13	Limit Stop	34	Checkstop
14	Sleeve	35	Bonnet Nut
15	Bonnet Retainer	36	Rubber Washer
16	Bonnet	37	Metal Washer
17	"O" Ring	38	Stem
18	"O" Ring	39	Rubber Disc
19	Washer	40	Checkstop
20	Spring		Body
21	Stem Assembly		

Available in Kits only

**Repair Kits List**

Repair Kits Number	Items Included
800-030	17, 18, 20, 22 (4), 28 (2), 30 (2), 34 (2)
800-031	17, 18, 22 (4), 23
800-032	12, 13, 17, 18, 19, 20, 21, 22 (2)

Repair parts sold only in kit form per above.

\* Not listed in parts price list as a standard replacement part.