




# Kitchen Single Control Pull Out Spray Spout Washerless 074 Series



Common Parts	Part No.
Button	99B3272
Handle Screw	99B3822
Hub Nut "O" Ring	99B4003
Cartridge	00A5013
"O" Ring	99B3235
Seal	99B3121
Hose Assembly	99B3932
Locknut	99B4144
Shank "O" Ring	99B3934
Mounting Gasket	99B3903
Weight Assembly	99B3927
Hose Washer	99B4113
Tailpiece Nut	99S0211
Friction Washer*	99B2774

\*not shown

### FINISH TRIM COMPONENTS

Parts	Chrome	White	Almond
<del>Handle Assy</del>	<del>00A2929</del>	<del>00W2929</del>	<del>00M2929</del>
<del>Hub Nut</del>	<del>99B3901</del>	<del>00W3901</del>	<del>00M3901</del>
<del>Shank Escutcheon</del>	<del>99B3933</del>	<del>00W3933</del>	<del>00M3933</del>
<del>Cover</del>	<del>99B3893</del>	<del>00W3893</del>	<del>00M3893</del>
Spray Head	99B3922	99B3922	00M3922

\*Single hole mount  
 †Mounting w/cover plate